Pobrano z mamadecor.pl

IL4057

LED GOOSE NECK FLOOR LAMP

INSTALLATION INSTRUCTIONS

These instructions are provided for your safety.
Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
* To prevent electrocution switch off at the mains supply before assembling or maintaining this product. Ensure the plug is not connected to any power supply and read instructions before assembly.
* Always unplug from the mains supply and allow the lamp to cool down before handling.
* **The light source of this luminaire is not replaceable; when the light source reaches the end of its end of life the whole luminaire shall be replaced.**

ASSEMBLY INSTRUCTIONS

1) Ensure product is not connected to the mains supply.

2) Unpack the product and remove all packaging. Take care not scratch the surface of the product whilst removing the plastic wrapping. Ensure the ends of the poles or the plug do not scratch base.

3) Lay the product out on the floor, having previously covered it with a soft cloth to avoid damage to the flooring and product finish. Assembly should take place with the product lying flat.

4) It may be necessary to remove protective packaging (plastic / cardboard) located at cable entry points of the product.

5) Screw first pole into main body of the floor lamp. j Take care to hold poles parallel to avoid cross threading. Hold the main body still and only turn the first pole, so as not to twist the cable.

6) Screw the bottom pole onto the assembled poles. k Hold the main body still and only rotate the bottom pole to prevent the cable becoming twisted.

7) Gently pull any excess cable out of the base until the lower pole meets the base.

8) Fit stem into the base l and fit the washer and retaining nut onto the all-thread protruding under the base then screw this into place then use a spanner to fully tighten the retaining nut. m

9) The product is now ready for use. Plug lamp in and switch it on.

Pobrano z mamadecor.pl



IL4057

GENERAL INFORMATION

This product is designed for internal use only. **Do not use polish or abrasive cleaner** ï just a soft dry cloth.

¢2 ₪ŜƎλăüŜ₪ è2dz₪ LJ₪2ŘdzŎú ₮2₪ l·yˇŜËüŜyŘŜŘ ₮λØŜπèŜl·₪ ø l·₪J₪l·yűèΣ LJfŜl·äŜ Ô2YˇLJfŜüŜ ûKŜ ăλYˇLJfŜ ₮2₪Yˇ l·ú

õ̃ õ̃ õ̃ ¢ŘI·₪fλƎKüλyƎ¢Ŏ2¢õ̃ ⟅κõ̃ l·₪J₪l·yűõ̃

2dzΩff yŜŜŘ ű2 ₮λff λyˇűKŜ ŘŜűl·λfă 2₮ űKŜ LJ₪2ŘdzŎűΣ ûKŜ ₪ŜűI·λfŜ₪ è2dz LJdz₪ŎKI·ăŜŘ λú ₮₪2YΣ l·yŘ l·fă2 ûKŜ λyãűl·ffŜ₪ l·yŘ ûKŜ λyãűl·ffl·ûλ2y¢ tfŜl·äŜ l·fă2 dzLJf2l·Ř l· ŎfŜl·₪ Ô2LJè 2₮ ûKŜ 2₪λƎλyl·f LJdz₪ŎKl·äŜ λyØ2λÔŜ 2₪ ₪ŜŎŜλLJű ű2 Ô2YˇLJfŜüŜ ûKλă ₪ŜƎλăú₪l·üλ2y¢

¦Yˇ ŘĮ₪ [λƎKűλyƎ [űŘΣ ² λfŘYˇŜ₪Ŝ w2l·ŘΣ. l·yõdz₪èΣ hË2yΣ h·mc o₩½

L₪Ŝfl·yŘ ƨ 9¦ˇ 5l·₪ [λƎKűλyƎ L₪Ŝfl·yŘ [λYˇλűŜŘΣ {dzλűŜ o ov ¢2dzãŜΣ mc Cdz₪ÎŜ w2l·ŘΣ {l·yŘèŧ2₪Ř LyŘdzăú₪λl·f 9ăűl·üŜΣ 5dzōfλyˇo o