Pobrano z mamadecor.pl



IL3361

FLOOR LAMP

These instructions are provided for your safety.
Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

* If the flexible cable of this product is damaged it should be exclusively replaced by the manufacturer or a similar qualified person in order to avoid a hazard.
* To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instruction before assembly.
* This fitting is fitted with a 3 Amp fuse and is suitable for 240 Volt ring mains.
* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
* When changing the bulb, ensure product is unplugged and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.

2. Lay the product out on the floor. If the floor is not carpeted please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat.

3. It may be necessary to remove protective packaging (plastic / cardboard) located at cable entry points of the product.

4. Screw the top pole onto the bulb holder section, take care to hold poles parallel to avoid cross threading. Hold upper section still and only turn lower pole so as not to twist the cable. j

5. Screw lower pole onto the upper pole, take care to hold poles parallel to avoid cross threading. Hold upper section still and only turn lower pole so as not to twist the cable. k

6. Turn the base onto the bottom pole. Keep the pole parallel to avoid cross threading. Keep the pole stationary and only rotate the base. l

7. Gently pull excess cable out of the base until the lower pole meets the base. m

8. Fit bulb: type and wattage as indicated on fitting. n **The wattage indicated must not be exceeded.**

9. Floor lamp is now ready for use.

Pobrano z mamadecor.pl



IL3361

GENERAL INFORMATION

This floor lamp is designed for internal use only.

Do not use polish or an abrasive cleaner - just a soft dry cloth.

¢2 ₪ŜƎƛăűŜ₪ è2dz₪ LJ₪2ŘdzŎűƬ2₪ Ɩ·yˇŜËűŜyŘŜŘ ƬƛØŜπèŜƖ·₪ ø Ɩ·₪J₪Ɩ·yűèΣ LJfŜƖ·ăŜ Ô2YˇLJfŜűŜ űKŜ ăƛYˇLJfŜ Ƭ2₪Yˇ Ɩ·ú

ő ő ő ΦŘƖ·₪fƛƎKűƛyƎΦŎ2Φő ⟅κő Ɩ·₪J₪Ɩ·yűő

2dzΩff yŜŜŘ ű2 ƬƛffˇƛyˇűKŜ ŘŜűƖ·ƛfă 2Ƭ űKŜ LJ₪2ŘdzŎűΣ űKŜ ₪ŜűƖ·ƛfŜ₪ è2dz LJdz₪ŎKƖ·ăŜŘ ƛú Ƭ₪2YΣ Ɩ·yŘ Ɩ·fă2 űKŜ ƛyãűƖ·ffŜ₪ Ɩ·yŘ űKŜ ƛyãűƖ·ffƖ·ûƛ2y¶ tfŜƖ·ăŜ Ɩ·fă2 dzLJf2Ɩ·Ř Ɩ· ŎfŜƖ·₪ Ŏ2LJè 2Ƭ űKŜ 2₪ƛƎƛyƖ·f LJdz₪ŎKƖ·ăŜ ƛyØ2ƛŎŜ 2₪ ₪ŜŎŜƛLJű ű2 Ŏ2YˇLJfŜűŜ űKƛă ₪ŜƎƛăű₪Ɩ·ûƛ2y¶

¦Yˇ ŘĮ₪ [ƛƎKűƛyƎ [űŘΣ ² ƛfŘˇYŜ₪Ŝ w2Ɩ·ŘΣ. Ɩ·yŏdz₪èΣ hĖ2yΣ h·mc o₩½

L₪ŜfƖ·yŘ ƨ 9¦ˇ 5Ɩ·₪ [ƛƎKűƛyƎ L₪ŜfƖ·yŘ [ƛYˇƛűŜŘΣ {dzƛűŜ o ov ϕ2dzãŜΣ mc Cdz₪ÎŜ w2Ɩ·ŘΣ {Ɩ·yŘèƬ2₪Ř LyŘdzăű₪ƛƖ·f 9ăűƖ·űŜΣ 5dzōfƛyˇo o