Pobrano z mamadecor.pl

IL2623

IP44 OUTDOOR WALL LIGHT

These instructions are provided for your safety.
Please read them carefully before commencing work and retain them for future reference.
This fitting has an IP rating of IP44 and is suitable for outdoor use when connected as instructed.

SAFETY INFORMATION

* It is recommended that this fitting is installed by a qualified electrician.
* This fitting should be fitted in accordance with IEE Wiring Regulations and relevant Building Regulations.
* To prevent electrocution switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electricity supply without your knowledge.
* If you are in doubt please consult a qualified electrician.
* To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
* This mirror is Class I = and should be fitted to a lighting supply protected by a 5 amp fuse or equivalent circuit breaker. If fitting in a bathroom the mirror should be connected to a supply protected by a 30mA RCD.
* Indicates that the fitting is suitable for mounting on normally flammable surfaces.
* This fitting is rated IP44 and is suitable for outdoor use when fitted in accordance with these instructions and IEE wiring regulations.
* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
* When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

INSTALLATION

Note: This fitting should only be installed in normal non aggressive atmospheric locations to prevent corrosion. Aggressive environments to be avoided include locations by the sea, polluted atmospheres or near heating flue outlets.


1. Ensure the house electricity supply is off at the fuse board.
2. If removing existing fitting, carefully note the position of each set of cables. If there are loop in cables that are not connected to the light these must be terminated in a separate terminal block not connected to the fitting.
3. Remove metal backplate from fitting by undoing retaining screw at the bottom of fitting, retain screw for later.
4. Remove metal fixing plate by undoing the 2 thumb nuts located on the front of the wall light cup, take care not to lose any parts.
5. Using metal fixing plate as a template, mark and drill fixing holes. Ensure holes are drilled into a solid wall or other suitable mounting. **Where required orientation arrow must be observed. (drain hole at the bottom)**
6. Carefully make a small hole in the soft rubber seal then feed supply cable though the seal whilst making sure it is correctly located onto metal fixing plate. Attach metal fixing plate onto the wall using suitable fixings. **Take care not to trap cable behind metal fixing plate.**
7. Make the electrical connections as follows, where required undo cable clamps by undoing retaining screws and make a small hole in the soft rubber grommet on terminal block.
   Connect supply live (normally brown or red) to fitting live (marked ñLò) on the terminal block.
   Connect supply neutral (normally blue or black) to fitting neutral (marked ñNò) on the terminal block.
   Connect supply earth (normally green/yellow or unsheathed) to earth (marked ñò) on terminal block.

   Ensure electrical connections are tight and no loose strands of wire are left out of the connector block refit terminal block back into position inside metal fixing plate. Ensure supply cable is clamped using the screw removed earlier.
8. Attach backplate over metal fixing plate and secure into place using 2 x thumb nuts and any washers retained from earlier.
9. Fit bulb, type and wattage as indicated on the fitting. **The wattage indicated must not be exceeded.**
10. Slide fitting (at a slight angle) over the top of metal backplate attached onto the wall and push the bottom part towards the wall then secure into position with the screw removed earlier whilst making sure the screw prevents fitting from being removed from the backplate.
11. Switch on the electricity supply at the fuse board.

GENERAL INFORMATION

This fitting is designed for external use, it must be fitted to a DRY FINISH as any dampness in concrete, wood stain, paint and etc can damage finish. **Do not use polish or abrasive cleaner - just a soft slightly damp cloth.**

Pobrano z mamadecor.pl



¢2 ℕŜƎƛăűŜℕ è2ɖzℕ LJℕ2ŘɖzÖű ₮2ℕ ł·yˇŜËűŜyŘŜŘ ₮ƛØŜπëŜł·ℕ ø ł·ℕJℕł·yűèΣ LJfŜł·äŜ Ö2YˇLJfŜűŜ űKŜ äƛYˇLJfŜ ₮2ℕYˇ ł·ű

õ õ õ ¢ŘI·ℕtƛƎKűƛyƎ¢Ö2¢õ ⟅κõ I·ℕJℕI·yűõ

ˏ2ɖzΩtf yŜŜŘ ű2 ₮ƛtf ƛyˇűKŜ ŘŜűł·ƛfă 2₮ űKŜ LJℕ2ŘɖzÖűΣ űKŜ ℕŜűł·ƛfŜℕ è2ɖz LJɖzℕŐKł·äŜŘ ƛű ₮ℕ2YΣ ł·yŘ ł·fă2 űKŜ ƛyăűł·ftŜℕ ł·yŘ űKŜ ƛyăűł·ftł·űλ2y¢ tfŜł·äŜ ł·fă2 ɖzLJf2l·Ř ł· ÖfŜł·ℕ Ö2LJè 2₮ űKŜ 2ℕƛƎƛyΠ·f LJɖzℕŐKł·äŜ ƛyØ2ƛÖŜ 2ℕ ℕŜŐŜƛLJű ű2 Ö2YˇLJfŜűŜ űKƛă ℕŜƎƛăűℕł·ûλ2y¢

¦Yʏ ŘŅℕ [ƛƎKűƛyƎ [űŘΣ ² ƛfŘYˇŜℕŜ w2l·ŘΣ. l·yŐɖzℕèΣ hÈ2yΣ h · мc oW½

LℕŜtł·yŘ ƨ 9¦ʏ 5l·ℕ [ƛƎKűƛyƎ LℕŜtł·yŘ [ƛYˇƛűŜŘΣ {ɖzƛűŜ o ov ¢2ɖzãŜΣ mc CɖzℕÎŜ w2l·ŘΣ {l·yŘè₮2ℕŘ LyŘɖzăűℕƛł·f 9ăül·űŜΣ 5ɖzōfƛyˇo o