Pobrano z mamadecor.pl



IL4245

IP65 OUTDOOR WALL

These instructions are provided for your safety.
Please read them carefully before commencing work and retain them for future reference.
This fitting has an IP rating of IP65 and is suitable for outdoor use when connected as instructed.

SAFETY INFORMATION

* We recommend any electrical wiring in an outdoor environment is carried out by a qualified electrician. All wiring must comply with the current edition of the IEE wiring regulations and any relevant Building Regulations.
* If you are in any doubt consult a person competent to give advice on the installation of electrical equipment.
* This fitting is Class I = and should be fitted to a lighting supply (with earth) protected by a 5 amp fuse or equivalent circuit breaker. Product should be connected to a supply protected by a 30mA RCD.
* This fitting is rated IP65 and is suitable for outdoor use when fitted in accordance with these instructions and IEE wiring regulations.
* Before installation and servicing disconnect the electricity supply at the fuse board.
* To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting.
* When changing the bulb, always switch off from the mains and allow old bulb to cool down before handling. Dispose of used bulbs carefully.

INSTALLATION

Note: This fitting has a 3 year guarantee against corrosion. This fitting should only be installed in normal non aggressive atmospheric locations to prevent corrosion. Aggressive environments to be avoided include locations by the sea, polluted atmospheres or near heating flue outlets.


1. Ensure the house electricity supply is off at the fuse board.
2. If removing existing fitting, carefully note the position of each set of cables. If there are loop in cables that are not connected to the light these must be terminated in a separate terminal block not connected to the fitting.
3. Remove the backplate from the facia by undoing the retaining screws, retain the screws and any washers for later.
4. Remove the terminal block cover by undoing the 2 x screws, retain the screws and any washers for later.
5. Using mounting bracket as a template, mark and drill fixing holes. Ensure holes are drilled into a solid wall or other suitable mounting.
6. Pass cable from the wall through the rubber grommet ensuring rubber grommet makes a good watertight seal around cable.
7. Attach the back plate onto the wall using suitable fixings whilst making sure the óO ringsô provided are used to prevent moisture ingress, take care not to overtighten screws or damage the óO ringsô
8. Make electrical connections as follows:
   Connect supply live (normally brown or red) to fitting live (marked ñLò) on the plastic casing terminal block.
   Connect supply neutral (normally blue or black) to fitting neutral (marked ñNò) on the plastic casing terminal block.
   Connect supply earth (normally green/yellow or unsheathed) to earth (marked ñò) on plastic casing terminal block.

   Ensure electrical connections are tight and no loose strands of wire are left out of the connector block and ensure terminal block and cable are not protruding.
9. Attach the terminal block cover using screws removed earlier whilst making sure wires do not obstruct fitment of the cover, use screws removed earlier to secure this into position whilst using any washers remover earlier where supplied. **Take care not to damage cable.**
10. Fit the candle drip over the lamp holder then fit bulb by using the tool provided, bulb type and wattage as indicated on the fitting. **The wattage indicated must not be exceeded.**
11. Attach the facia over backplate then secure this into position using screws and any óO ringsô removed earlier, **take care not to over tighten**.
12. Switch on the electricity supply at the fuse board.

GENERAL INFORMATION

This fitting is designed for external use, it must be fitted to a DRY FINISH as any dampness in concrete, wood stain, paint and etc can damage finish. **Do not use polish or abrasive cleaner - just a soft slightly damp cloth**

Pobrano z mamadecor.pl



¢2 ŇŜƎƛăűŜŇ è2ʤŇ LJŇ2ŘʤŐű ŦŁŇ ł·ƴŜĚűŜyŘŜŘ ŦƛØŜπèŜł·Ň ø ł·ŇŇł·ýűèΣ LJfŜł·ăŜ Ő2ƳLJfŜűŜ űĶŜ ăƛƳLJfŜ ŦŁŇƳ ł·ű

õ õ õ ¢Řł·ŇtƛƎKűƛyƎ¢Ő2¢õ ⟅κõ ł·ŇŇł·ýűõ

ˏ2ʤΩtf yŜŜŘ ű2 Ŧƛtf ƛƴűĶŜ ŘŜűł·ƛťă 2Ŧ űĶŜ LJŇ2ŘʤzŐűΣ űĶŜ ŇŜűł·ƛfŜŇ è2ʤz LJdzŇŐĶł·ăŜŘ ƛű ŦŇ2ƳΣ ł·yŘ ł·ťă2 űĶŜ ƛyăűł·ffŜŇ ł·yŘ űĶŜ ƛyăűł·ffł·ű ƛ2y¢ t fŜł·ăŜ ł·ťă2 ʤzLJf2ł·Ř ł· ŐfŜł·Ň Ő2LJè 2Ŧ űĶŜ 2ŇƛƎƛył·f LJdzŇŐĶł·ăŜ ƛy¢2ƛŐŜ 2Ň ŇŜŐŜƛLJű ű2 Ő2ƳLJfŜűŜ űĶƛă ŇŜƎƛăűŇł·ű ƛ2y¢

¦ YƳ ŘŅŇ [ƛƎKűƛyƎ [űŘΣ ² ƛfŘƳŜŇŜ w2ł·ŘΣ. ł·yŐʤzŇèΣ hÈ2yΣ h · мc oW½

LŇŜfł·yŘ ƨ 9¦ƳƳ 5ł·Ň [ƛƎKűƛyƎ LŇŜfł·yŘ [ƛƳƛűŜŘΣ {ʤzƛűŜ o ov ¢2ʤzãŜΣ mc CʤzŇÎŜ w2ł·ŘΣ {ł·yŘè Ł2ŇŘ LyŘʤzăűŇƛł·f 9ăüł·űŜΣ 5ʤzōfƛƴo o