Pobrano z mamadecor.pl



IL4326

TOWER FLOOR LAMP

ASSEMBLY INSTRUCTIONS

These instructions are provided for your safety.
Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

* The supply cable runs through the inside of this product. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Do not exceed the wattage stated.
* When changing the bulb, always unplug from the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Take care not scratch the surface of the poles whilst removing the plastic wrapping. Ensure the ends of the poles or the plug do not scratch base.
2. Lay the product out on the floor, having previously covered it with a soft cloth to avoid damage to the flooring and product finish. Assembly should take place with the product lying flat.
3. It may be necessary to remove protective packaging (plastic / cardboard) located at cable entry points of the product.
4. Screw the upper pole section onto the bulb holder section. Hold the bulb holder section still and only rotate the upper pole to prevent the cable becoming twisted. ¡
5. Screw the lower pole section onto the upper pole section. Hold the upper assembly still and only rotate the lower pole to prevent the cable becoming twisted ¢
6. Rotate the base section onto the assembled poles. Keep the assembled parts still and rotate only the base section. £
7. Stand the floor lamp upright then ensure all the assembled parts are fully tightened.
8. Fit the bulb: mType and wattage as indicated on the fitting. **The wattage indicated must not be exceeded.**
9. Your lamp is now ready for use. n

GENERAL INFORMATION

This product is designed for internal use only. **Do not use polish or abrasive cleaner ï just a soft dry cloth.**

¢2 NJŜƎƛǎüŜNJ è2dzNJ LJNJ2ŘdzÔűŭ Ŧ2NJ Ⅰ·ƴ´ŜĖüŜyŘŜŘ ŦƛØŜπèŜⅠ·NJ ø Ⅰ·NJNJⅠ·yűüèΣ LJfŜⅠ·ăŜ Ô2ƳLJfŜűŜ űKŜ ăƛƳLJfŜ Ŧ2NJƳ´ Ⅰ·ŭ

õ õ õ ϕŘⅠ·NJŧƛƎKűƛyƎΦÔ2ϕõ ⌈κõ Ⅰ·NJNJⅠ·yűõ

¸2dzDtf yŜŜŘ ű2 Ŧƛtf ƛƴ´ŭKŜ ŘŜűⅠ·ƛťă 2Ŧ űKŜ LJNJ2ŘdzÔűΣ ŭKŜ NJŜűⅠ·ƛfŜNJ è2dz LJdzNJÔKⅠ·ăŜŘ ƛű ŦNJ2YΣ Ⅰ·yŘ Ⅰ·fă2 ŭKŜ ƛ˚ăüⅠ·ffŜNJ Ⅰ·yŘ ŭKŜ ƛyãűⅠ·ffⅠ·ŭƛ2y¶ tfŜⅠ·ăŜ Ⅰ·fă2 dzLJf2Ⅰ·Ř Ⅰ· ÔtŜⅠ·NJ Ô2LJè 2Ŧ ŭKŜ 2NJƛƎƛƴ·f LJdzNJÔKⅠ·ăŜ ƛyØ2ƛÔŜ 2NJ NJŜÔŜƛLJű ű2 Ô2YLJfŜűŜ ŭKƛă NJŜƎƛǎüNJⅠ·ŭƛ2y¶

¦YƳ ŘŅNJ [ƛƎKűƛyƎ [ŭŘΣ ² ƛfŘYŜNJŜ w2Ⅰ·ŘΣ. Ⅰ·yÕdzNJèΣ hÈ2yΣ h · мс oW½

LNJŜfⅠ·yŘ ƨ 9¦Ƴ 5Ⅰ·NJ [ƛƎKűƛyƎ LNJŜfⅠ·yŘ [ƛY´ƛűŜŘΣ {dzƛűŜ o ov ϕ2dzãŜΣ mc CdzNJÎŜ w2Ⅰ·ŘΣ {Ⅰ·yŘèŦ2NJŘ LyŘdzăűNJƛⅠ·f 9ăüⅠ·ŭŜΣ 5dzōfƛy´o o

Pobrano z mamadecor.pl

IL4326

