Pobrano z mamadecor.pl

INSTALLATION MANUAL

62130F


ecopanel

230V | SMD **4014** | **30**W | **IP40** | Die cast
Complete with 700mA driver.

80 CRI

300mm
39mm


one LIGHT




A Connect the power wires using the connector.
L (brown/red) - Live
N (blue/black) - Neutral


B Fix the base plate on the ceiling using screws.

C Match the fix points



D Close the fitting by turning it clockwise, open it by turning it counterclockwise





PAY ATTENTION TO THE LABEL

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.