
INSTALLATION MANUAL

63100N, 63150N, 63200N


ecolight | 80 CRI | RoHS COMPLIANT | NOT DIMMABLE | 40cm

230V | SMD **2835** | **100W** / **150W** / **200W** | IP**65** | High Bay | Aluminium | Complete with driver


63100N




63150N




63200N




A Tighten the loop and fix loop screw, make sure it's stable.



B Put the high bay into hook and make it safe



C Connect the power wire: Brown, "L" connect to LIVE / Blue, "N" connect to NEUTRAL / Yellow-Green, connect to EARTH/GROUND



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.