Pobrano z mamadecor.pl


INSTALLATION MANUAL

65170AT

ecotracklight | 90 CRI | CE RoHS COMPLIANT | NOT DIMMABLE


30W | SMD **3030** | **230**V | **50/60**Hz | IP**20** | Aluminium

Complete with 700mA driver.




one LIGHT

1




To mount the track adaptor into the track system, ensure that the selector knob Ⓐ is at OFF position and the adaptor lock Ⓑ is disengaged.

2




When installing the adaptor into the track, ensure that it is orientated correctly.

3




Rotate adaptor lock Ⓑ clockwise 90° to connect the adaptor to the neutral circuit.

4




Rotate security button Ⓑ anticlockwise 90° to secure track light to the track.

5




Rotate selector knob Ⓐ to the position of desired circuit.

5a




Circuit 1: Rotate the knob Ⓐ 90° clockwise from the starting position OFF, to connect circuit 1.

5b




Circuit 2: Rotate the knob Ⓐ 90° anti-clockwise from the starting position OFF, to connect circuit 2.

5c



Circuit 3: Rotate the knob Ⓐ 180° clockwise from the starting position OFF, to connect circuit 3.

6



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
/ÞAIþkIqþ`IsboþqebþqqfkdÞ
3. Maintenance and installation should only be carried out by a professional electrician.