
Pobrano z mamadecor.pl

# **INSTALLATION** MANUAL


## 65406BT

ecotrackspot | ADJUSTABLE | RoHS COMPLIANT | NOT DIMMABLE


**15**W | **230**V | **50/60**Hz | **IP20** | Die cast | Adjustable | Complete with 350mA driver | 90 CRI





one LIGHT





To mount the track adaptor into the track system, check that both tabs Ⓐ & Ⓑ on the adaptor are in the “open” position and insert into the track.





Ensure the track adaptor is inserted with the correct orientation.





Rotate tab Ⓐ clockwise 90° to connect the adaptor to the neutral circuit.





Rotate tab Ⓑ to the desired position circuit.





**Unconnected:** The luminaire is fixed to the track but not connected to any circuit.





**Circuit 1:** To connect to circuit 1, from the starting position, rotate the tab Ⓑ clockwise 90°.




**Circuit 2:** To connect to circuit 2, from the starting position, rotate the tab Ⓑ anti-clockwise 90°.




**Circuit 3:** To connect to circuit 3, from the starting position, pull the tab Ⓑ down and rotate anti-clockwise 90°.



**Warnings:**

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.

www.1-light.eu